

# Pioneer

## Service Manual

ORDER NO.  
**CRT4501**

CD RECEIVER

# DEH-P4200UB<sub>/XNUC</sub>



This service manual should be used together with the following manual(s) listed below. For the parts numbers, adjustments, etc. which are not shown in this manual, refer to the following manual(s).

Model No.	Order No.	Mech. Module	Remarks
DEH-5200SD/XNEW5	CRT4508		
CX-3269	CRT4488	S11STD-DOUT	CD Mech. Module : Circuit Descriptions, Mech. Descriptions, Disassembly

1 2 3 4

# SAFETY INFORMATION

**WARNING**

This product may contain a chemical known to the State of California to cause cancer, or birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 - Proposition 65

## EXPLODED VIEWS AND PARTS LIST PACKING(Page 36)

**PACKING SECTION PARTS LIST**

\*:Non spare part

Mark	No.	Description	DEH-5200SD/XNEW5	DEH-P4200UB/XNUC	
B	1	Cord Assy	CDP1268	CDP1269	
	2	Polyethylene Bag	CEG-162	CEG1173	
	3	Unit Box	QHG3057	QHG3070	
	4	Contain Box	QHL3057	QHL3070	
	5	Case Assy	YXB5009	Not used	
C	6	Accessory Assy	YEA5083	*YEA5071	
	13	Protector	YHP5063	CHP3962	
	14	Protector	YHP5064	CHP3963	
	15	Remote Control Unit	Not used	CXE2758	
D	16	CD-ROM	QPJ3003	Not used	
	*	17-1	Caution Card	CRP1389	Not used
	*	17-2	Caution Card	CRP1394	Not used
	*	17-3	Passport	CRY1268	Not used
	*	17-4	Warranty Card	CRY1279	CRY1276
		17-5	Quick start GUI Manual	QRD3042	Not used
		17-6	Installation Manual	QRD3044	QRD3054
		17-8	Operation Manual	Not used	QRD3053
			Screw Assy	Not used	YEA5072
		*	Polyethylene Bag	Not used	CEG-127
		Screw	Not used	CRZ50P090FTC	
		Screw	Not used	TRZ50P080FTC	

**Operation Manual, Installation Manual**

Part No.	Language
QRD3053	English, French, Spanish
QRD3054	English, French, Spanish

Diagram showing exploded view of packing parts: CEG-127 (Polyethylene Bag), YEA5072 (Accessory Assy), CRZ50P090FTC (Screw), and TRZ50P080FTC (Screw).

DEH-P4200UB/XNUC

1 2 3 4

**EXTERIOR(1)(Page 38)****EXTERIOR(1) SECTION PARTS LIST**

Mark	No.	Description	DEH-5200SD/XNEW5	DEH-P4200UB/XNUC
	1	Cord Assy	CDP1268	CDP1269
	4	Detachable Assy	QXA3213	QXA3236
	15	Grille Unit	CXE2895	CXE3000
	17	Button Unit	CXE2511	*CXE3004
	24	Remote Control Unit	Not used	CXE2758
	25	Cover	Not used	CNS7068

**EXTERIOR(2)(Page 40)****EXTERIOR(2) SECTION PARTS LIST**

Mark	No.	Description	DEH-5200SD/XNEW5	DEH-P4200UB/XNUC
	10	Tuner Amp Assy	QWM3122	QWM3151
	15	Holder	CND5410	QNC3016
	16	Holder	CND5417	Not used
	25	Panel	CNU1015	CNU1017

# ELECTRICAL PARTS LIST(Page 70)

## Tuner Amp Assy

Circuit Symbol and No.	Part Name	DEH-5200SD/XNEW5	DEH-P4200UB/XNUC
IC101	IC	Not used	HA12241FP
IC451	IC	Not used	SST25V040BIS
IC601	IC	PEG645A8	PEG684A8
Q101	Transistor	Not used	LSA1576UB
Q102	Transistor	Not used	LTC114EUB
Q781	Chip Transistor	2SB1689	Not used
Q782	Transistor	LTC114EUB	Not used
Q783	Transistor	DTA123EU	Not used
Q951	Transistor	LSA1576UB	Not used
D951	Diode	MC2848-11	Not used
L951	Chip Coil	BTH1101	Not used
CN781	Connector	CKS6180	Not used
JA101	Connector	Not used	CKS5271
R101		Not used	RS1/16SS620J
R103		Not used	RS1/16SS101J
R104		Not used	RS1/16SS101J
R105		Not used	RS1/16SS102J
R106		Not used	RS1/16SS222J
R107		Not used	RS1/16SS223J
R108		Not used	RS1/16SS472J
R109		Not used	RS1/16SS181J
R110		Not used	RS1/16SS181J
R111		Not used	RS1/16SS223J
R112		Not used	RS1/16SS223J
R113		Not used	RS1/16SS102J
R114		Not used	RS1/16SS102J
R402		RS1/16SS681J	Not used
R410		Not used	RS1/16SS823J
R411		Not used	RS1/16SS823J
R412		RS1/16SS0R0J	Not used
R451		Not used	RS1/16SS0R0J
R454		Not used	RS1/16SS101J
R455		Not used	RS1/16SS101J
R456		Not used	RS1/16SS101J
R457		Not used	RS1/16SS101J
R458		Not used	RS1/16SS473J
R533		RS1/16SS221J	Not used
R541		RS1/16SS473J	Not used
R611		Not used	RS1/16SS472J
R612		Not used	RS1/16SS472J

Circuit Symbol and No.	Part Name	DEH-5200SD/XNEW5	DEH-P4200UB/XNUC
R621		RS1/16SS104J	Not used
R781		RS1/16SS221J	Not used
R782		RS1/16SS221J	Not used
R783		RS1/16SS221J	Not used
R785		RS1/16SS221J	Not used
R786		RS1/16SS221J	Not used
R787		RS1/16SS221J	Not used
R789		RS1/16SS103J	Not used
R790		RS1/16SS681J	Not used
R791		Not used	RS1/16SS0R0J
R794		RS1/16SS331J	Not used
R951		RS1/16SS102J	Not used
R952		RS1/16SS223J	Not used
R954		RS1/16SS153J	Not used
C101		Not used	CKSSYB104K16
C186		Not used	CKSSYB105K6R3
C204		Not used	CKSRYB105K10
C205		Not used	CKSRYB105K10
C206		Not used	CKSRYB105K10
C207		Not used	CKSRYB105K10
C409		Not used	CKSSYB152K50
C410		Not used	CKSSYB152K50
C451		Not used	CKSSYB104K10
C641	2.2 uF	CKSRYB105K10	CCG1179
C689		CCSSCH8R0D50	Not used
C951		CKSSYB104K16	Not used

For the information of the parts that are added to this model, please refer to the following manual (CRT4508).